

AHT Liftgates, LLC 309 Mogie Ln. Acworth, Ga. 30102 (770) 425-5480 E-Mail: parts@ahtliftgates.com Web: www.ahtliftgates.com

STEEL TROUBLESHOOTING GUIDE

PROBLEM	CAUSE	CORRECTION
MOTOR SOUNDS	1) Low hydraulic oil	- Put platform on ground. Check oil level. Add new oil to within 1" from top of
STRANGE		tank.
	2) Shuttle Valve Defective	- Remove shuttle valve, dismantle it and blow it out with air. Reassemble and
		reinstall. Be careful not to over tighten. If still not working replace.
	3) Motor Defective	- Replace motor